SUZUKI テンプルブロック STE-500 取扱説明書

この度はテンプルブロック STE-500 をお買い上げいただきまして、誠にありがとうございます。本製品を末永く、正しくお使いいただくため、この取扱説明書をよくお読みください。お読みになった取扱説明書はなくさないよう、大切に保管しておいてください。

⚠ ご使用上の注意

- ブロックの上に乗ったり、遊んだりしないでください。また、マレット以外の重いもの、角ばったもの、金属などでたたかないでください。本製品をいためる原因、または思わぬ怪我の原因にもなります。
- 本製品がよごれたら乾いたやわらかい布で拭いてください。油類（シンナー・ベンジン等）は使用しないでください。本製品をいためる原因になります。
- かならず平らな場所へ設置してください。また、移動する際にブロックを持つことはしないでください。静かに運ぶように心がけてください。
- 組み立てやスタンドの調節の際、可動部へ指を挟まないようにご注意ください。

○ 内容品



○ 組み立てかた

開梱時、スタンドに付属しているボルトをとりはずし、以下の図の様に取り付けていきます。



○ 三脚スタンドの調節方法

三脚を開く 図1のツマミをゆるめ、可動部を押し下げてください。適当な位置まできたら、しっかりとツマミを締め、固定してください。

図1



高さを調節する スタンド上部（図2）のレバーを手前に開きバーの高さを調節してください。適当な位置まで来たら、レバーを戻し固定してください。
固定があまい場合、（図3）のネジを締めて調節してください。

図2



図3



※金具やネジを操作する際は、テンプルブロック本体を支えながら行ってください。本体が急に下がってくるなど、思わぬ怪我の原因になる恐れがあります。

○ いい音を出すには

中心や奥をたたくといい音がでません。ブロックの手前をマレットで弾むようにたたいてください。



○ 仕　様

材　質：木製ブロックタイプ５音
寸　法：ブロック本体 51×8.8cm
　　三脚スタンド 約70～95cm
　　（高さ調節可能）
重　量：ブロック本体 1.3kg
　　三脚スタンド 2.9kg

株式会社 鈴木楽器製作所
〒430-0852　静岡県浜松市中区領家2-25-12　tel：(053)461-2325

00457-20012
V1.00

SUZUKI TEMPLE BLOCK STE-500 OWNER'S MANUAL

We are pleased to introduce to you the Suzuki STE-500 Temple Block. For your safety and long term use of the STE-500, please read and follow this instruction manual. Thank you very much for your purchase.

⚠ CAUTION

- Excess pressure (i.e. standing on) or hitting hard can result in damage or injury.
- Do not strike blocks with anything heavier than a mallet. Any sharp object or metallic object will damage the blocks.
- Clean this instrument with a dry soft cloth. Do not use alcohol, thinner's or petro-chemical-based polishes.
- Use this instrument on a flat surface. Be careful when moving and avoid handling the individual blocks.
- Take care when assembling the instrument and also when adjusting the height.

○ COMPONENTS



○ ASSEMBLING

Remove the bolt from the tripod stand.
Assemble as the drawing shows.



○ ADJUSTING THE TRIPOD

>> **To open the tripod,** loosen the finger screw (see **Figure 1**) and push the stand down. Adjust it and tighten the finger screw firmly.

Figure1



>> **To adjust the height,** open the lever (see **Figure 2**), adjust the height and close the lever. Tighten the screw to fix into position (see **Figure 3**).

Figure2



Figure3



Hold the Temple Block body during assembly or adjustment to avoid the blocks falling, which could be a hazard to yourself or the instrument.

○ HOW TO PLAY

Strike the front side of the body with a mallet, as the centre and rear side will not make an ideal sound.



○ SPECIFICATION

MATERIAL : Wooden blocks (5 notes)
DIMENSION : Block body　51cm x 8.8cm (20" x 3.5")
　　Tripod stand 70～95cm (27.5"～37.5")
WEIGHT : Block body　1.3kg (2.85 lb)
　　Tripod stand 2.9kg (6.4 lb)

SUZUKI MUSICAL INST. MFG. CO.,LTD.
Hamamatsu, Japan